

Assembly Instructions for Electric Hydro Bike

Step 1

Remove boat and tower from box.



Step 2

Place boat on center of the cross bars. Making sure that rear of boat is to the rear of the floats.
(Rear of floats has release valves)



Step 3

Attach engine to transom using existing hardware.

Step 4

Attach left hand deck using supplied hardware (nuts and wing-nuts).



Step 5

Attach right side deck, making sure plastic wing-nut is inserted in the rear inside hole prior to slipping it in place.



Step 6

Attach tower to two outside wing-nuts (one on right side, one on left side).
Apply the two rear bolts on the rear bracket.



Step 7

Install the lower steering arm clevis pin at this point.

Then adjust your upper steering arm with 2 allen screws. The Electric Hydro Bike assembly is complete.