

## Table of figures

Figure 1: Operation manual and warning signs on the access side of the rotating parking system .....	8
Figure 2: Control box.....	8
Figure 3: Platform select buttons .....	9
Figure 4: Control key – position “0” .....	10
Figure 5: Control key – position “1” .....	10
Figure 6: Emergency STOP button .....	10
Figure 7: Platform number marking – front side .....	11
Figure 8: Platform number marking – side marking .....	11
Figure 9: Free parking platform at level “0” .....	13
Figure 10: Occupied parking platform at level “0” .....	13
Figure 11: Correct entry at the rotary parking with the front side of the vehicle .....	14
Figure 12: Incorrect entry at the rotary parking with the back side of the vehicle .....	14
Figure 13: Wheel lanes at the parking platform .....	15
Figure 14: Correct positioning of the wheels during vehicle entry.....	15
Figure 15: Correct positioning of the wheels on the wheel lanes .....	16
Figure 16: Mirror on the front of the rotary parking for wheel positioning control .....	16
Figure 17: Safety barriers on the wheel lanes .....	17
Figure 18: Correct positioning of the wheels between two barriers.....	18
Figure 19: Warning sign for forbidden climbing on platform .....	22
Figure 20: Warning sign for forbidden entry during system operation.....	22