

# 6 NAVIGATION & OPERATION

## 6.1 Use of Engines

The craft is fitted with the following motive power:

Engine Electric Motor

Piktronik SYS100


Gearbox: N/A

Propeller As supplied by manufacturer

Information Before starting the engine:

- Check the bilge water level.
- Ensure that ventilation openings are clear to prevent overheating

Avoid placing flammable materials on or near hot parts.

	<p>Caution</p>	<p>So as to avoid moving parts, never access the engine space when engines are running.</p>
---	----------------	---